		9		0.00		
High-pres	sure weld eter					
Measuring	g resistor: Worotective to					
	neasuring r					
	_	explosion pr				
• max. 540	0 °C (1004 0 44, mat. N	7MC101	0 - <b>G</b> A	2		
• max. 550	0 °C (1022 Fi 17 122, r	7 M C 1 0 1	0 - <b>F</b> A	2		
	g insert with					
• max. 550	0 °C (1022 Ti 17 122, r	7 M C 1 0 1	0 - <b>F</b> E	2		
2 Pt100 m	neasuring r	esistors/tw	o-wire circuit			
	g insert not					
	0 °C (1004 5 44, mat. N	7MC101	0 - ■GB	2		
• max. 550	0°С (1022 Гі 17 122, г	7 M C 1 0 1	0 - ■ F B	2		
		explosion p				
• max. 550 CrNiMoT	0°С (1022 Гі 17 122, г	7MC101	0 - <b>F</b> F	2		
Mounting length U	Protective tube	Total length	Weight with one/two			
	length L		measuring resistors			
mm (inch)	mm (inch)	mm (inch)	kg (lb)			
65 (2.6)	140 (5.5)	305 (12.0)	0.78 (1.7)/ 0.79 (1.7)	-	1	
		365 (14.4)	0.82 (1.8)/		2	
		395 (15.6)	0.83 (1.8) 0.85 (1.9)/		3	
			0.86 (1.9)			
		365 (14.4)	0.95 (2.1)/ 0.96 (2.1)		4	
		395 (15.6)	0.98 (2.2)/		5	
		365 (14.4)	1.00 (2.2) 0.95 (2.1)/		6	
125 (4.9)	200 (7.9)	, ,	0.96 (2.1)		ď	
		395 (15.6)	0.98 (2.2)/ 1.00 (2.2		7	
	260 (10.2)	395 (15.6)	1.15 (2.5)/ 1.20 (2.7)		8	
	on head, fo					
made of c and	ast light all	by, with 1 ca	ble bushing			
• screw co						ŀ
<ul> <li>standard</li> </ul>	d hinged co			(		
• high hin				1		
<ul> <li>high hing made of s and screw</li> </ul>	tainless ste	el, with 1 ca	ble bushing			ŀ

Order No.

Selection and Ordering data

Selection and Ordering data	Order No.					
Further designs Please add "-Z" to Order No. and specify Order code(s) and plain text.	Order code					
Different design (mounting length, protective tube material etc.), specify in plain text.	Y01					
TAG plate made of stainless steel specify TAG No. in plain text	Y15					
Calibration carried out at one point, specify desired temperature in plain text (order equivalent number of times for several calibration points).  If optional head transmitters are integrated, please note that all calibration points are located in the set measuring range. If the points are located outside the standard measuring range, a Y11 addition is always required.	Y33					
To order a temperature transmitter installed in the connection head						

and transmitters for SIL applications, see "Temperature transmitters for mounting in the connection head" (page 3/79).

Individual parts: Measuring inserts and connection heads, see "Accessories".