Internal interconnection of the phases in the ammeter changeover contact for the prevention of voltage peaks at the connections of the current transformers:

connections of the current transformers:				
	Switch position	Short-circuited phases		
		L1	L2	L3
	0	✓	✓	✓
	L1		✓	✓
	L2	✓		✓
	L3	✓	✓	